


# EXOCET SAFETY

EXOCET SAFETY IS AN INTEGRATED SOLUTION THAT CENTRALIZES ALL YOUR SHIP'S SAFETY FUNCTIONS.

Designed to react automatically in certain critical situations, EXOCET Safety guarantees enhanced safety at sea.

Our unique platform **monitors, detects and acts** to protect your crew and your boat, combining cutting-edge technology with ease of use.

## MAIN FEATURES



**MAN OVERBOARD  
MANAGEMENT**



**WATER INTRUSION  
DETECTION**



**RIG MONITORING**



**WEATHER AND  
THUNDERSTORM  
MONITORING**



**ALERT  
CENTRALIZATION**



**ANTI CAPSIZE AND  
HEEL CONTROL**



**ANCHORING  
MONITORING**



**ENERGY CONSUMPTION  
MONITORING**



**ANTI-COLLISION  
DEVICE**  
*(optional, from 2025)*



## EXOCET SAFETY OFFER


from €10,950 excl. VAT

- An Exocet SAFETY box with 8 safety functions\*
- Two connection cables: CAN + CAN Ethernet
- A user guide
- EXOCET Safety keypad
- 1 buzzer alarm box
- Analog Exoconnect
- Serial Exoconnect

\* A ninth feature will be available as an option in 2025: anti-collision functionality



# HOW IT WORKS?



## INFORMS THE CREW



### SENSORS

- GPS
- Navigation unit
- Attitude sensors
- Load sensors
- Water intrusion sensors
- External alarms...

- ANTI CAPSIZE AND HEEL CONTROL
- MAN OVERBOARD MANAGEMENT
- WEATHER AND THUNDERSTORM MONITORING
- ENERGY CONSUMPTION MONITORING
- WATER INTRUSION DETECTION
- ALERTS CENTRALIZATION
- RIGGING MONITORING
- ANCHORING MONITORING
- ANTI COLLISION (2025)



OPTIONAL ACTIVATION

## ACTS AUTOMATICALLY




Course change with autopilot command



Sails release

# PERIPHERAL PRODUCTS


### EXOCET SAFETY KEYBOARD



12-key marinized keyboard: 9 for function activation, 1 to acknowledge all alerts, 1 to give control back to the autopilot and 1 to release sails.

512€ excl VAT

### EXOCET VOICE ALARM



Alerts and informs the crew of an event detected by your Exocet box, using a phrase. The Exocet uses artificial intelligence to transcribe a text notification into a synthesized voice. It enhances the effectiveness of the alarms relayed by the buzzer in the basic package.

Please contact us

### EXOCET SAIL RELEASE SYSTEM



Complete mechanical and electronic system with clam cleat to automatically release a sheet. System includes : release cleat, air tank, compressor and control valve.

Please contact us

### EXOCET DIGITAL CONNECTION BOX



Digital input box for connecting up to 16 external devices (4 peripheral alarms and 12 water intrusion sensors) and sending their information back to the EXOCET system

Please contact us

### WATER INTRUSION SENSOR



Installed at strategic points on the boat to detect the presence of water. Sensor supplied with 6m cable for direct connection to Exocet Safety. To combine with EXOCET digital connection box to connect up to 12 water intrusion sensors.

Please contact us

### EXOCET CLOUD SUBSCRIPTION



For remote access to Exocet Safety system data.

From €100 excl. VAT / month

# PACKAGES PERIPHERALS

Anti capsizes and heel control	.....	On request
<ul style="list-style-type: none"> <li>✓ Sail release system</li> <li>✓ Heel sensor</li> <li>✓ Out digital interface</li> </ul>		
Internet connectivity package	.....	On request
<ul style="list-style-type: none"> <li>✓ 4G router and Wifi access point</li> </ul>		
Rig monitoring package	.....	On request
<ul style="list-style-type: none"> <li>✓ Stay and shrouds loadpins</li> <li>✓ NMEA2000 signal amplifiers</li> </ul>		
Man Over Board device package	.....	On request
<ul style="list-style-type: none"> <li>✓ MOB button NMEA2000</li> <li>✓ Man overboard detection crew beacon(s)</li> <li>✓ Personal AIS beacon(s)</li> <li>✓ Jon Buoy</li> </ul>		
Anti-collision package	.....	On request
<ul style="list-style-type: none"> <li>✓ Compatible radar</li> <li>✓ Radar display</li> <li>✓ Thermal Camera</li> </ul>		



PIXEL SUR MER

# FEATURE SPECIFICATIONS

PREREQUISITES: NAVIGATION UNIT, AUTOPILOT, AIS SYSTEM, GPS.

FUNCTIONALITY	REQUIRED EQUIPMENTS	OPTIONAL EQUIPMENTS
<b>Man overboard management</b>	<ul style="list-style-type: none"> <li>✓ Trigger: Alert button and/or AIS beacon and/or /Navigation software and/or Man Over Board button</li> <li>✓ Audible alarm box</li> <li>✓ Display screen</li> </ul>	<ul style="list-style-type: none"> <li>✓ Listening release system</li> <li>✓ Voice alarm box</li> <li>✓ Exocet Safety keypad</li> </ul>
<b>Weather and thunderstorm monitoring</b>	<ul style="list-style-type: none"> <li>✓ Barometer</li> <li>✓ Audible alarm box</li> <li>✓ Display screen</li> </ul>	<ul style="list-style-type: none"> <li>✓ internet connectivity package</li> <li>✓ Voice alarm box</li> <li>✓ Exocet Safety keypad</li> </ul>
<b>Anchoring monitoring</b>	<ul style="list-style-type: none"> <li>✓ Audible alarm box</li> </ul>	<ul style="list-style-type: none"> <li>✓ Depth sensor</li> <li>✓ Voice alarm box</li> <li>✓ Exocet Safety keypad</li> </ul>
<b>Water intrusion detection</b>	<ul style="list-style-type: none"> <li>✓ Exocet Digital Input</li> <li>✓ Audible alarm box</li> <li>✓ At least 1 Water intrusion sensor</li> <li>✓ Display screen</li> </ul>	<ul style="list-style-type: none"> <li>✓ Voice alarm box</li> <li>✓ Up to 11 additional intrusion sensors</li> <li>✓ Exocet Safety keypad</li> </ul>
<b>Alert centralization</b>	<ul style="list-style-type: none"> <li>✓ Audible alarm box</li> <li>✓ Display screen</li> </ul>	<ul style="list-style-type: none"> <li>✓ Exocet Digital Input for connecting up to 4 additional external alarms in addition to the Exocet Safety's direct alarm connection</li> <li>✓ Voice alarm box</li> <li>✓ Exocet Safety keypad</li> </ul>
<b>Energy consumption monitoring</b>	<ul style="list-style-type: none"> <li>✓ NMEA 2000-compatible battery system</li> <li>✓ Audible alarm box</li> <li>✓ Display screen</li> </ul>	<ul style="list-style-type: none"> <li>✓ Voice alarm box</li> <li>✓ Exocet Safety keypad</li> </ul>
<b>Rig monitoring</b>	<ul style="list-style-type: none"> <li>✓ At least 1 load cell</li> <li>✓ Audible alarm box</li> <li>✓ Display screen</li> </ul>	<ul style="list-style-type: none"> <li>✓ up to 13 additional load cells</li> <li>✓ Voice alarm box</li> <li>✓ Exocet Safety keypad</li> <li>✓ Listening release system</li> </ul>
<b>Anti capsizes and heel control</b>	<ul style="list-style-type: none"> <li>✓ Attitude sensor</li> <li>✓ Audible alarm box</li> <li>✓ Display screen</li> </ul>	<ul style="list-style-type: none"> <li>✓ Voice alarm box</li> <li>✓ Listening release system</li> <li>✓ Exocet Safety keypad</li> </ul>
<b>Anti-collision and obstacle avoidance system</b>	<ul style="list-style-type: none"> <li>✓ At least 1 of : AIS, Sea AI camera, Radar</li> <li>✓ Compass</li> <li>✓ Audible alarm box</li> <li>✓ Display screen</li> </ul>	<ul style="list-style-type: none"> <li>✓ Voice alarm box</li> <li>✓ Listening release system</li> <li>✓ Exocet Safety keypad</li> </ul>

## SPECIFICATIONS

### PHYSICAL AND ENVIRONMENTAL

- ✓ Weight: 350 g
- ✓ Size: 113 x 97 x 40mm
- ✓ Materials: Anodized aluminum
- ✓ Operating temperature : -10°C / +50°C
- ✓ Water resistance: IP67
- ✓ Input voltage: 9 - 51V
- ✓ Power consumption: 4W
- ✓ Certifications : CE EN 60945 and FCC

### INPUT/OUTPUT INTERFACES

- ✓ 1x Ethernet
- ✓ 2x CAN 2.0
- ✓ 6x Analog inputs - 16 bits 50 Hz
- ✓ 2x Digital contact inputs
- ✓ 3x Digital contact outputs
- ✓ 5x RS232 series
- ✓ 1x RS232 / RS422 series

## APPLICATIONS

- SIMPLIFY YOUR LIFE WITH ENHANCED SECURITY
- BE READY TO REACT IN AN INSTANT
- AUTOMATE YOUR SECURITY
- SAIL WITH PEACE OF MIND
- ANTICIPATE BREAKDOWNS, KEEP YOUR VESSEL PERFORMING OPTIMALLY

PIXEL SUR MER – [www.pixelsurmer.com](http://www.pixelsurmer.com)

Lorient La Base, Bâtiment Kerguelen 7 rue Lt Bourely 56100 Lorient - France  
[sales@pixelsurmer.com](mailto:sales@pixelsurmer.com) - Tel : + (33) 2 30 90 50 18



PIXEL SUR MER